

Product Specification

11/2019

Product TFT LCD Display

Mode APT TFT500C

Abbreviation 500C

Client

Customer

audit

Supplier Tianjin APT Science and Technology Co., Ltd.

1001, Building 5 HuaDing, No.1 HuaKe 3 Road, Binhai hi-tech Industrial Development Zone, Tianjin, China

Tel TEL:+86 22 83715556
FAX:+86 22 83719955

Email yzhao@aptdevelop.com

1. Product Name

- ✧ TFT LCD display
- ✧ Model : APT TFT 500C

2. Suppliers

- ✧ Tianjin APT Science and Technology Co., Ltd.
- ✧ Email : yzhao@aptdevelop.com apt@aptdevelop.com

3. Electrical Parameters

- ✧ 2.2inch TFT screen
- ✧ 24V/36V/48V battery supply
- ✧ Rated operating current : 40mA
- ✧ Off leakage current < 1uA
- ✧ Max output current to controller : 100mA
- ✧ Operating temperature : -20~70℃, Storage temperature : -30~80℃

4. Dimensions & Material

- ✧ Product shell is ABS, transparent window is made with high strength Acrylic.
- ✧ Dimensions : host/L79mm*W40mm*H18mm




5. Features

- ✧ Suitable for low temperature, Max -20℃.
- ✧ High-contrast 2.2inch IPS colorful matrix screen.
- ✧ Ergonomic external button design, easy to operate.

- ✧ **Speed display** : AVG SPEED, MAX SPEED, SPEED(Real-time).
- ✧ **Kilometer / Mile** : Can be set according to customers' habits.
- ✧ **Smart battery indicator** : Provide a reliable battery indicator.
- ✧ **9-level Assist** : 3-level/5-level/9-level optional.
- ✧ **Mileage indicator** : Odometer/Trip distance/Riding time.
- ✧ **Power indicator** : real time power indicator, digital or analog.
- ✧ **Speed limit value indicator**
- ✧ **Error code indicator.**
- ✧ **Software upgraded** : Software can be upgraded through UART.

6. TFT screen instructions



7. Functional Description




7.1 Power On/Off

Press and hold **Power** button for 1 second can turn on/off the display. The Display can automatically shut down when there is no operate & ride for X minutes (X could be 0~9) .

*If the display has been set password power on, you need to input the right password before start.

7.2 Assist level operating

Short press **UP/DOWN** button can change the assist level. Top assist level is 9, 0 for neutral. Level quantities can be adjusted according to the customer requirements.



7.3 Speed & Mileage mode switch

Short press **POWER** button can change the speed and mileage mode, TRIP→TIME→ODO→AVG SPEED→MAX SPEED.




**If there is no operation for 5 seconds, display will return Speed (Real-Time) display automatically.

7.4 Headlight/backlight On/Off


Press and hold **UP** button for 1 second can turn on/off the headlight.

*The motor does not work when the battery voltage is low, Display still can keep the headlight on for a while when E-bike is in riding.



7.5 Walking mode (6km)

Press and hold **DOWN** button for 2 second can get into walking mode, out of the mode when release the button.



* This feature needs to be supported by controller.

7.6 Data cleanup

Press and hold **UP** & **DOWN** buttons together for 1 second can reset several temporary data, temporary data include **AVG Speed / MAX Speed / Trip / Time**.

* These temporary data can't be erased by power off.

8. Parameter setting

Press **M** button (press no less than 2second) can get into setting menus, press **UP/DOWN** buttons to change the parameter setting, press **M** button can switch to next item. Press **M** (press no less than 2second) button will exit from menu.

* Display will automatically quit menu when there is no operation for 30 seconds.


* For safety reasons, display can't get into MENU when riding.

* Display will quit MENU when start riding.

The order of parameters are as follow.

MENU	
System Metric	Brightness
Auto off 5 min	Battery 36 V
Battery Ind Voltage	More >

8.1 System : Press Up / Down button to switch between Metric / Imperial.



8.2 Brightness : Press Up / Down button to change the brightness of the backlight, **I** is darkness, **|||||** is brightness



8.3 Auto off : Press UP/DOWN button to change the auto power off time, from 1 to 9/OFF, the number represent time (minutes) to shutdown, OFF means disable auto off function, default value is 5 minutes.



8.4 Battery : Press UP/DOWN will change battery voltage setting, optional value is 24V/36V/48V.




8.5 Battery Ind : Press UP/DOWN button to change the battery indicator, Voltage / Percentage / OFF.


*Accurate percentage needs communication with battery.



8.6 Advance setting : Press **M** button can get into the advance setting menu, default password is '1919'.



8.7 Wheel : Press UP/DOWN can change the wheel setting, optional wheel diameter is 12/14/16/18/20/22/24/26/27/27.5/28/29/30/31 inch.



8.8 Speed limit : Press UP/DOWN will change speed limit, range 10km/h~41km/h. Default value is 25km/h.



8.9 Speed poles : Magnetic poles inside the motor, press UP/DOWN will change pole number, range 0~10. Default value is 1.




8.10 Start poles : How many poles (speed sensor) need to be detected by controller before starting motor. Default value is 3.




8.11 Assist levels : This parameter can customize assist levels, options are 3/5/9.




8.12 PIN ON : This parameter can set Start input, options are No/Yes, If you had set Start input **Yes**, you must input right password before power on, password is accorded to your setting.




8.13 PIN Num : This parameter can set password number you need.




You need to input the right password before start with 30 seconds, display will power off automatically if the password was wrong.



9. Error Code define

500C can show warning message,  icon shows on the screen, and show error code at the bottom of the screen, error code from 21~30, and the definition see the table below.

Error Code	Error description	Handle
0x21	Current protection	Check controller.
0x22	Throttle error	Check throttle and connection.
0x23	three-phase power error	Check three-phase power line connection
0x24	Hall error	Check the hall connection
0x25	Brake error	Check the brake connection.
26-99	Reserved	Please contact the controller's manufacturer for error definitions
0x30	Communication Error	Check the cable connection




10. Assembly instructions



Please pay attention to the screw's torque value, damaged caused by excessive torque

is not within the scope of the warranty.

11. Connector descriptions



- 1、 Red wire : Anode(24v/36v/48V)
- 2、 Blue wire : Power cord to the controller
- 3、 Black wire : GND
- 4、 Green wire : RxD (controller -> display)
- 5、 Yellow wire : TxD (display -> controller)

12. Assist level instructions

Assist level can be customized, the highest level is 9, common used assist level see the table below:

3 level	5 level	9 level	
0	0	0	No power assist
	1	1	
		2	
1	2	3	
		4	
	3	5	
2		6	
	4	7	
		8	
3	5	9	

13. Certification

CE / IP65 (water proof) / ROHS.