



Designed and made in
Canada by Grin
Technologies Ltd.




Grin Technologies
205-950 Powell Street
Vancouver, BC V6A 1H9

info@ebikes.ca
www.ebikes.ca




TorqArmV3



TorqArmV3

For use on front forks without threaded fender eyelets, or where the eyelet hole doesn't line up.

Attaches to the fork with hose-clamps.



Installation Notes

- Tighten the 1/4" bolt between the axle plate and the arm as snug as possible (8Nm).
- The tolerances on motor axles can vary from the nominal 10mm. The plate may slide on freely with a bit of play, it may go on perfectly snug, or in some cases a small amount of filing may be necessary for the plate to slide on.
- Many dropouts have quick release "lawyer lips" that come out sideways and prevent the torque plate from sitting flat against the dropout. Use the included "spacer 'C' washer" under the torque plate for a flush fit.
- Heat-shrink tube over the stainless steel hose-clamp band makes the installation more discreet and protects the paint job. Several pieces of shrink tube are included inside this package, and can be cut to size as required.

For more information, visit www.ebikes.ca

