



Grin Technologies  
205-950 Powell Street  
Vancouver, BC V6A 1H9




Designed and made in  
Canada by Grin  
Technologies Ltd.

info@ebikes.ca  
www.ebikes.ca

# TorqArm311

## Installation

1. Connect the Axle Plate, Spacer, Arm, and washers using the M6 Bolt as shown in diagram. Leave the M6 Bolt loose for now. The two M6 Washers can be arranged on either side of the Arm, depending on your bicycle's fork spacing.




2. Insert the motor axle directly into the Axle Plate. This replaces the motor's inside keyed washer. 

3. Install the motor axle in the bicycle's dropout, and secure with the motor's hardware (washers and bolts).

4. Attach the Arm to the bicycle fork's eyelet using the included M5 Bolt and washer. Re-arrange the M6 washers for spacing if needed. Tighten all bolts.

For more information, visit [www.ebikes.ca](http://www.ebikes.ca)

# TorqArm311



For Use With Bafang G311  
Front Geared Hub Motors  
on Forks with Threaded  
Fender Eyelets

Installs Only on Left (Disk)  
Side of Motor



Advancing the world of  
ebike parts and accessories [www.ebikes.ca](http://www.ebikes.ca)

